

XSIGHT 100™

X-RAY SYSTEM FOR MAIL AND PARCEL INSPECTION

Features:

- Protect your staff with the isolated and secure, high capacity security screening unit
- Compact system can accept bundles of mail, small parcels and mail bags
- Transfer system between locations with optional wheel base
- Multi level energy control enhances sensitivity when detecting explosives, fine wires, incendiary devices and drugs
- Ultra high definition flat screen enables instant and positive identification of contents
- Advanced image characterization software to identify and isolate potential threats quickly
- State of the art image archival system to download and save images for future reference
- Twin circuit door safety interlocks to meet US FDA CFR 1020.40 Section 21 specifications

Specifications:

- Chamber capacity - H: 420mm W: 380 mm D: 420 mm
- Physical dimensions - H: 1400mm W: 430mm D: 550mm
- Controls - Mains on/off switch
- X-ray source - 80 kV with multi level energy control
- Image Archival - CD and USB based Memory stick interface
- Security key switch
- Power requirement - 110/220/240V 50/60 Hz supply 1kW

Options:

- Video Printer
- Color based Image Enhancement software

Specifications are subject to change without notice.